Technicolor DWA0100 & TD5336

You can apply this procedure on computer, PlayStation, XBOX, Nintendo and any other gaming device

PlayStation 4

In order to solve your PS4 problem please follow the below steps

- Step 1: Firstly navigate to the settings menu on your PS4
- Step 2: Next select Network
- Step 3: You need to select "set up internet connection"
- Step 4: You need to select "custom"
- Step 5: You need now to select the method in which your PS4 connects to the internet
- Step 6: Make sure to set your IP address manually
- Step 7: Enter the desired IP address that you would like to use for your PlayStation[®]4.
 - ▶IP Address: 192.168.1.50
 - >Subnet Mask: 255.255.255.0
 - > Default Router: 192.168.1.1 (IP Address of your router)
 - Primary DNS: 193.227.177.130
 - ≻Secondary DNS: 194.126.16.38
- Step 8: In MTU Settings, select automatic.
- Step 9: In Proxy servers , select Do Not Use
- Step 10: Select TEST Internet Connection.
- Step 11: Connect a device to your Technicolor modem (using cable / WIFI)
- Step 12: In your browser enter the address 192.168.1.1
- Step 13: You will be prompted to enter Username and password , Username is Administrator and Password should be printed on the label on the backside of modem
- Step 14: Expand Advanced then click Firewall and scroll down to DMZ
- Step 15: Enable DMZ and select correct DSL interface
- Step 16: Type 192.168.1.50 in DMZ Host IP Address then click Apply to save configuration

technicolor technicolor VL	DSL Router English V Logout
 Site contents: SETUP ADVANCED Advanced Wireless Multi-WAN Advanced-LAN IPv6 WAN IPv6 LAN DSL Settings RIP Settings NAT Firewall Static Route Multicast Dynamic DNS DNS Route Port Mapping Quality of Service UPnP SHARE MAINTENANCE STATUS 	 ○ Disable ● Enable → 3 □ ppp0 ↓ 4 192.168.1.50 ↓ 5 △ Apply ← 6

• Step 17: Reboot your PS4 and your NAT type problem should be solved

PlayStation 3

In order to solve your PS3 problem please follow the below steps:

- Step 1: On your PS3: Go to network settings then Internet connection settings a
- Step 2: Choose the type of connection you are using (wired/wireless) then choose Manual IP and enter the following IP addresses:
 - > IP Address: 192.168.1.50
 - Subnet Mask: 255.255.255.0
 - Default Router: 192.168.1.1
 - Primary DNS: 193.227.177.130
 - Secondary DNS: 194.126.16.38
- Step 3: Disable the UPnP and leave the rest of the setting as they are
- Step 4: Connect a device to your Technicolor modem (using cable / WIFI)
- Step 5: In your browser enter the address 192.168.1.1
- Step 6: You will be prompted to enter Username and password , Username is Administrator and Password should be printed on the label on the backside of modem
- Step 7: Expand Advanced then click Firewall and scroll down to DMZ

- Step 8: Enable DMZ and select correct DSL interface
- Step 9: Type 192.168.1.50 in DMZ Host IP Address then click Apply to save configuration

technicolor	technicolor VD	OSL Router	English 🗸	Logout
Site contents: SETUP ADVANCED Advanced Wireless Multi-WAN Advanced-LAN IPv6 WAN IPv6 LAN SL Settings RIP Settings NAT Firewall Static Route Multicast Dynamic DNS DNS Route Port Mapping Quality of Service UPnP SNMP SHARE MAINTENANCE STATUS	Firewall DMZ 1 DMZ DSL Interface DMZ Host IP Address 2	 ○ Disable ● Enable → 3 ppp0 ↓ ↓ 192.168.1.50 ↓ 5 Apply ← 6 		

• Step 10: Reboot your PS3 and your NAT type problem should be solved

Laptop or Desktop

In order to solve your gaming problem on your computer please follow the below steps

- Step 1: Click Start then Control Panel
- Step 2: Click on network and internet then network and sharing center
- Step 3: When the Network and Sharing Center opens, click on Change adapter settings.
- Step 4: Right-click on your local or wireless adapter and select Properties
- Step 5: In the Local Area Connection Properties window double-click Internet Protocol Version 4 (TCP/IPv4)
- Step 6: Select use the following IP address and enter IPs and Subnet Mask
 - > IP Address: 192.168.1.50
 - Subnet Mask: 255.255.255.0
 - > Default Router: 192.168.1.1 (IP Address of your router)
- Step 7: Then enter your Preferred and Alternate DNS server addresses
 - Primary DNS: 193.227.177.130
 - Secondary DNS: 194.126.16.38
- Step 8: Connect a device to your Technicolor modem (using cable / WIFI)

- Step 9: In your browser enter the address 192.168.1.1
- Step 10: You will be prompted to enter Username and password , Username is Administrator and Password should be printed on the label on the backside of modem
- Step 11: Expand Advanced then click Firewall and scroll down to DMZ
- Step 12: Enable DMZ and select correct DSL interface
- Step 13: Type 192.168.1.50 in DMZ Host IP Address then click Apply to save configuration

technicolor t	technicolor VL	OSL Router	English 🔽	Logout
Site contents: SETUP ADVANCED Advanced Wireless Multi-WAN Advanced-LAN IPv6 LAN DSL Settings RIP Settings NAT Static Route Multicast Dynamic DNS DNS Route Port Mapping Quality of Service UPnP SNMP SHARE MAINTENANCE STATUS	Firewall DMZ	 ○ Disable ● Enable		

• Step 14: Reboot your computer to solve gaming problem.