# TP-Link TD-W8968 V4

- Establish a connection between the device and the router via network cable or Wi-Fi , If Wi-Fi is protected by a password look at sticker on bottom side
- Open your web browser and type the default IP Address 192.168.1.1 in the address bar

http://192.168.1.1/ - Windows Internet Explorer

http://192.168.1.1/

- You should now see the router login page with 2 text fields where you can type a username and a password
- The default username is admin and password is admin

admin

admin

Login

Copyright © 2015 TP-LINK Technologies Co., Ltd. All rights reserved.

- After logging in , Click Quick Setup then click Next

TP-LINK

300Mbps Wireless N USB ADSL2+ Modem Router
Model No. TD-W8968

Device Info
Quick Setup
Operation Mode
Advanced Setup
IPTV
Wireless
Guest Network
USB Settings
Diagnostics
Management
Logout

Quick Setup - Start

This guide will help you set basic parameters for Internet connection. Please click NEXT to continue.

For function or parameters in details, please click the corresponding menu on the left.

Next

- Select ADSL Modem Router as Operation Mode then click Next

- Select other for country and ISP
- Type VPI and VCI , VPI Should be 0 in case DSP is Ogero and 8 in case DSP is GDS while VCI should be 35 then click Next
- Select LLC/SNAP-BRIDGING as Encapsulation Mode and PPPoE(PPP Over Ethernet) as WAN Link Type
- Type ADSL Username and Password then click Next

- Make sure wireless adapter is enabled then In Wireless Network Name type Wi-Fi name
- Select WPA2-Personal as Network Authentication then type wireless password in Wireless Network Key and click Next (safest passwords are long and contain at least 8 digits of mixed letters, and numbers)

- Review configuration Summary then click Confirm