Netis DL43 Series

- Establish a connection between the device and the router via network cable or Wi-Fi (if there's a WIFI password you have to check bottom of the router. If you turn the router over, you should see a sticker, and one of the pieces of information should say something like "Wi-Fi Password" or "WPA passcode.")
- Open your web browser and enter **http://192.168.1.1** in the browser address bar
- Type Username: guest and password: guest to login to modem's interface

ADSL Router Login

| User Name: | guest |
| Password: | ●●●●● guest |

Login   **Reset**

- Click START to run Quick Start guide

> **Quick Start**

> Quick Start ⬅

This Modem Router is ideal for home networking and small business networking. The 'Quick Start' wizard will guide you to configure the Modem router to connect to your ISP (Internet Service Provider).

START **EXIT**

- The Wizard will guide you through these four quick steps. Begin by clicking on NEXT

Quick Start

The Wizard will guide you through these four quick steps. Begin by clicking on NEXT

Step 1. PVC Auto Searching

Step 2. Set your Internet connection

Step 3. Wireless network configuration

Step 4. Save settings of this ADSL Router

NEXT   EXIT

- Click cancel to input VPI and VCI Manually

Message from webpage

Wait a minute. It will take a moment to search for the available PVC.--
Click YES.
If you know the correct PVC (VPI/VCI) from your ISP, you may also
input the value manually--Click NO.

OK   Cancel

- Keep Auto PVC disabled then enter VPI and VCI , VPI should be 0 if DSP is Ogero and 8 if DSP is GDS while VCI should be 35 then click Next

Quick Start--DSL Setting

Enable PVC Auto Search:

PVC Auto Search Result:

VPI: 8   (0~255)

VCI: 35   (32~65535)

BACK   NEXT   EXIT

- Choose PPPoE as ISP connection type then click Next

- Type ADSL username and password and make sure connection type is PPPoE LLC then click Next

- In SSID textbox type the name of wireless connection
- Make sure Authentication type is WPA-PSK/WPA2-PSK then type wireless password and click NEXT (and safest passwords are long and contain at least 8 digits of mixed letters, and numbers)

Quick Start---Wireless Setting

You may enable/disable Wireless, change the Wireless SSID and Authentication type in this page.
Click NEXT to continue.

Access Point:	● Activated ○ Deactivated
SSID:	netis
Broadcast SSID:	● Yes ○ No
Authentication Type :	WPA-PSK/WPA2-PSK ▾
Password:	password (Please enter ASCII characters between 8 and 63 or Hexadecimal characters between 8 and 64.)

BACK NEXT EXIT

- One the Wizard is completed click Next to save configuration

Quick Start Completed!!

The Setup Wizard has completed. Click on BACK to modify changes or mistakes. Click NEXT to save the current settings.

BACK NEXT EXIT

- Click close to go back to main page

Quick Start Completed!!

Saved Changes!

ClOSE